

# Verifi™

## LURE

1. For use only with Verifi™ Bed Bug Detector.
2. Remove a Verifi Lure from the packaging. **DO NOT REMOVE THE FOIL FROM THE VERIFI LURE.**

3. Remove a Verifi lure from the packaging and place it foil side up on a table. Remove the Verifi lure activation tool from the packaging and carefully place the activation tool over the Verifi lure. Be sure to fit the larger section of the lure activation tool over the larger section of the capsule. Press down, so that the tool pierces the foil. **[Figure 1]** Remove the tool from the lure capsule and there will be two small holes in the top of the foil. **[Figure 2]** Insert the Verifi Lure completely into slots in the Verifi Core with the foil facing the Verifi Core and the larger part of the Verifi Lure on the bottom. **[Figure 3]** The pins inside the lure activation tool may be sharp, do not place your finger inside tool.




Figure 1




Figure 2




Figure 3

4. Slide the Verifi Core into the Verifi Holster with the Lure facing the front of the Verifi Holster. Be sure that the Verifi Core completely snaps into the Verifi Holster.
5. Secure the Verifi Bed Bug Detector with a zip tie to prevent exposure or access to the internal components.

For additional information, please visit our website at [www.fmcprosolutions.com](http://www.fmcprosolutions.com) or call 1-800-321-1362, option 3.

© 2011 FMC Corporation. All Rights Reserved. Patents pending. Verifi is a trademark of FMC.

**Net Contents:**  
**1 x 12 Blister Packs (12 Verifi Lures)**

# FMC

FMC Corporation  
 Agricultural Products Group  
 1735 Market Street  
 Philadelphia, PA 19103

**Precautions:** Contains n-Nonane: Flammable liquid and vapor. Harmful if inhaled. May cause skin and eye irritation. Avoid contact with skin or eyes or breathing vapor.\*

<b>FIRST AID</b>	
<b>IF INHALED</b>	<ul style="list-style-type: none"><li>• Move person to fresh air.</li><li>• If person is not breathing, call 911 or an ambulance, then give artificial respiration, preferably by mouth-to-mouth, if possible.</li><li>• Call a poison control center or doctor for further treatment advice</li></ul>
<b>IF ON SKIN OR CLOTHING</b>	<ul style="list-style-type: none"><li>• Take off contaminated clothing.</li><li>• Rinse skin immediately with plenty of water for 15-20 minutes.</li><li>• Call a poison control center or doctor for treatment advice.</li></ul>
<b>IF IN EYES</b>	<ul style="list-style-type: none"><li>• Hold eye open and rinse slowly and gently with water for 15-20 minutes.</li><li>• Remove contact lenses, if present, after the first 5 minutes, then continue rinsing eye.</li><li>• Call a poison control center or doctor for treatment advice.</li></ul>
<b>IF SWALLOWED</b>	<ul style="list-style-type: none"><li>• Call a poison control center or doctor immediately for treatment advice.</li><li>• Have person sip a glass of water if able to swallow.</li><li>• Do not induce vomiting unless told to do so by the poison control center or doctor.</li><li>• Do not give anything by mouth to an unconscious person.</li></ul>
<b>HOTLINE NUMBER:</b> Have the product container or label with you when calling a poison control center or doctor, or going for treatment. You may also contact 1-800-331-3148 for emergency medical treatment information. For Information Regarding the Use of this Product Call 1-800-321-1FMC (1362)	

\*When used as directed, does not expose persons to harmful levels of vapors.

#### **Limitation of Liability and Damages:**

FMC Corporation believes that the information and recommendations contained herein (including data and statements) are accurate as of the date hereof. The information provided herein relates only to the specific product designated and may not be applicable where such product is used in combination with any other materials or in any process. Further, since the conditions and methods of use are beyond the control of FMC Corporation, FMC Corporation expressly disclaims any and all liability as to any results obtained or arising from any use of the product or reliance on such information. **NO WARRANTY OF FITNESS FOR ANY PARTICULAR PURPOSE, WARRANTY OF MERCHANTABILITY, OR ANY OTHER WARRANTY, EXPRESSED OR IMPLIED, IS MADE WITH RESPECT TO THE SELECTION, PURCHASE, OR USE OF THIS PRODUCT OR THE INFORMATION PROVIDED HEREIN. THE EXCLUSIVE REMEDY OF THE USER OR BUYER, AND THE EXCLUSIVE LIABILITY OF FMC AND SELLER FOR ANY AND ALL CLAIMS, LOSSES, INJURIES OR DAMAGES (INCLUDING CLAIMS BASED ON BREACH OF WARRANTY, CONTRACT, NEGLIGENCE, TORT, STRICT LIABILITY OR OTHERWISE) RESULTING FROM THE USE OR HANDLING OF THIS PRODUCT, SHALL BE THE RETURN OF THE PURCHASE PRICE OF THE PRODUCT OR, AT THE ELECTION OF FMC OR SELLER, THE REPLACEMENT OF THE PRODUCT.** This Conditions of Sale and Limitation of Warranty and Liability may not be amended by any oral or written agreement.